

SABRE

ADVANCED 3D SURVEYING SYSTEMS



SABRE SKY-3D™ LiDAR Payload with FARO Focus High-Resolution 3D Point Cloud Data

Introduction

The SABRE SKY-3D™ is an integrated 3D high-resolution airborne mobile mapping system specifically used for a diverse range of applications including geospatial, security, defence, law enforcement, coast guard, construction, maintenance of existing infrastructure.

The SABRE SKY-3D™ supports the interface with the FARO high precision laser scanners, enabling the LiDAR system to capture high-resolution data of up to 2 million points per second. The system is complemented with high-resolution imagery using an optional FLIR camera system.

The SABRE SKY-3D™ system is fully-interoperable and compatible with the range of FARO Focus S model laser scanners, and has been designed to complement the characteristics of the FARO Focus S model laser scanners to deliver the best in market airborne mobile mapping solutions.

UAV LiDAR - A View from Above - Advantageous airborne operated LiDAR

Airborne LiDAR systems offer Rapid survey of areas within difficult, inaccessible or dangerous situations for ground-based survey.

- ☑ Compatible with FARO Focus S Models S350 Plus, S150 Plus, S350, S150, S70
- ☑ High-Resolution High-Quality 3D Data
- ☑ Enabling Rapid Deployment Capability
- ☑ Up to ~ 2 million points per second
- ☑ High Productivity for Optimising ROI



Fig 1. SABRE SKY-3D LiDAR Payload deployed on Multirotor Drone Platform.

Mounting of LiDAR systems on Drone Platforms provides enhanced results with the coverage being improved by the LOS (line-of-sight). This is achieved by having a high-angled view-point from above reducing blind-spot areas when compared against the view-point seen from ground level using conventionally operated vehicle mounted LiDAR systems. The perspective of data acquisition at height also maximises the range capabilities of the utilised laser using a more ideal perpendicular angle of incidence encountered by the laser-beam.

SABRE Sky-3D UAV/Drone LiDAR

The SABRE Sky-3D UAV LiDAR is a remote sensor payload that can attach to an aerial platform UAV/Drone. The Sky-3D remote payload sensor system has further benefit in that it can be deployed on a wide range of drones capable of carrying the payload weight and dimensions.




Fig 2. SABRE SKY-3D™ LiDAR Data 3D Point Cloud

Single-Beam LiDAR for Precise Results

The Airborne LiDAR SABRE SKY-3D F-S system uses a single-beam which is accurately calibrated, delivering survey-grade results superior to other comparative airborne LiDAR equipment on the market.

Airborne Deployment


Using the SABRE SKY-3D™ airborne mobile mapping enables high-resolution laser scanning capability for areas inaccessible to conventional techniques.

- ✓ SABRE SKY-3D™ Airborne Mobile Mapping Equipment enables the generation of High-Definition 3D point clouds with high-precision and absolute accuracy.
- ✓ Rapidly Survey Large Areas / opening up new opportunities.
- ✓ Providing accurate 3D information that can be measured.
- ✓ **Risk Reduction:** Increased safety by survey from the air.
- ✓ **High-Resolution:** Detailed 3D Point Cloud data allowing quality assurance of repeatable results for supporting confident information extraction.



Fig 3. SABRE SKY-3D LiDAR Payload Deployed on Multirotor Drone Platform.

Fig 4. SABRE SKY-3D™ LiDAR Data 3D Point Cloud



Key Features and Functionality

- ✔ Compatible with FARO Focus S laser scanner models: Focus S350 Plus, S150 Plus, S350, S150, S70 FARO Focus S 'A' Type laser scanner required.
- ✔ Up to ~ 2 million points per second for FARO Focus S350 Plus and Focus S150 Plus Laser Scanners.
- ✔ Quick-Release to allow FARO Focus Laser Scanner to be used for static tripod base laser scanners.
- ✔ Auxiliary expansion ports for Georeferenced imagery for Positioned and Orientated Imagery.

- ✔ Distance Range:
up to 350 metres (Focus S350 / S350 Plus)
- ✔ Resolution:
up to ~ 2 million points per second

Key Benefits

- ✔ Universal LiDAR payload system attachable for UAV/Drone deployment
- ✔ Rapidly Survey Large Areas / Opening up New Opportunities
- ✔ Accessibility to 3D mapping of difficult or inaccessible areas
- ✔ Accelerate Productivity and Project Delivery
- ✔ Easy Deployment
- ✔ Effective and Efficient 3D Data Collection
- ✔ Providing you with Accurate 3D Information you can measure
- ✔ Risk Reduction: Increased Safety by survey from the security of a vehicle
- ✔ High-Resolution: Detailed 3D Point Cloud Data allowing confident information extraction
- ✔ FARO Focus S compatible
- ✔ High-Resolution: Detailed 3D Point Cloud data allowing confident information extraction.

Technical Specification

General Specification

- ✔ Payload Weight: 5.5 Kg
- ✔ Input Voltage: 14 - 20 VDC
- ✔ Power Consumption: 140 W, Max 10 A
- ✔ External Logging USB 2.0 Device Port
- ✔ PC Memory Storage

Typical Survey Parameters

- ✔ Typical Survey Flight Speed: 5 m/s
- ✔ Typical Altitude: 40 m

Environmental Characteristics

- ✔ Operating: 0° - +50° C
- ✔ Storage: -10° - +60°C
- ✔ IP Rating: IP 54

3D Point Cloud Data Output

- ✔ Export File Formats: PTS, LAS, E57

GNSS-Inertial Navigation System

- ✔ Manufacturer: Applanix
- ✔ System/Model: APX-20 UAV
- ✔ Provides High Performance Direct Georeferencing

LiDAR / Laser Scanner

- ✔ Compatible Laser Scanners FARO Focus S 'A' Type Models: S350 Plus, S150 Plus, S350, S150, S70
- ✔ Ranging Distance: up to 350 m (Focus S 350)
- ✔ Ranging Error(1): ±1 mm (Focus S)
- ✔ Resolution: up to 2 million Points/Sec (Focus S Plus)
- ✔ Vertical Field of View: 300° (Focus S)
- ✔ Angular Accuracy: 19 arcsec for vertical/horizontal angles
- ✔ Beam Divergence 0.3mrad (1/e)
- ✔ Max. Scan Speed: 97Hz (vertical)
- ✔ Environmental IP Rating: IP 54
- ✔ Wavelength 1550nm
- ✔ Safety: Class 1 (Focus S)
- ✔ See manufactures latest technical data sheet for performance specification.

See manufactures technical data sheet for full performance specification.

Software

- ✔ Post-Processing Software: POSPac UAV
- ✔ Post-Processed Differential GNSS-Inertial SW for the APX-20 UAV INS.
- ✔ Post-Processing software is used to import the raw INS data and either base station or third-party RTK correction data to generate a precise post-processed solution.



High-Lighted Performance Specification

Performance PP(2) Specifications (RMS Error):

- ☑ Position Vertical (m): 0.05
- ☑ Velocity (m/s): 0.010
- ☑ Roll & Pitch (deg) 0.015
- ☑ True Heading (deg) 0.035
- ☑ Supports GPS, GLONASS, BeiDou, Galileo, QZSS, SBAS
- ☑ Type of positioning system: MEMS IMU (MICROELECTROMECHANICAL GYRO)

Data Logging

- ☑ IMU Data rate: 200 Hz
- ☑ Internal Logging 6GByte Flash memory

See manufactures technical data sheet for full performance specification.

Kit Contents

Main Components of the SABRE Sky-3D :

- ☑ FARO Focus S laser scanner compatible interface
- ☑ Survey-Grade GNSS-INS
- ☑ Power Unit / Pack
- ☑ Internal memory Data Storage
- ☑ Embedded PC.
- ☑ SABRE Processing Software License (USB Dongle)
- ☑ Optional Payload Dampener.

- ☑ Optional Camera system for High-Resolution Georeferenced Imagery.
- ☑ Survey-Grade INS for Accurate Position and Orientation for capture camera images.
- ☑ 3D Point Cloud colourisation

Camera Imaging System

SABRE SKY-3D™ Georeferenced Camera Imagery, for Photogrammetry and 3D Point Cloud Colourisation.

Accessory (Optional) Camera Kit for SABRE SKY-3D™ for SABRE Georeferencing for Positioned and Orientated Imagery.

- ☑ Manufacture: FLIR
- ☑ Camera Family: Grasshopper™3
- ☑ Model Number: GS3-U3-120S6C-C
- ☑ Imaging Device: Sony ICX834
- ☑ Type: Colour Camera
- ☑ Type of Shutter: Global
- ☑ Resolution (MegaPixels): 12.00
- ☑ Pixels (H x V): 4,240 x 2,824
- ☑ Pixel Size, H x V (µm): 3.1 x 3.1
- ☑ Frame Rate (fps): 7
- ☑ Camera Sensor Format: 1"

Notes:

- 1 Ranging error is defined as a systematic measurement error at around 10m and 25m.
- 2 Outage Duration 0 sec, Typical performance - actual results are dependent upon satellite configuration, atmospheric conditions and other environmental factors.

See manufactures technical data sheet for full performance specification.

Subject to change without prior notice.

SABRE
ADVANCED 3D SURVEYING SYSTEMS

+44 (0) 1330 820225
info@sabreadvanced3d.com
www.sabreadvanced3d.com

